



EZUp Instruction kit

Amarok EZUp Hoodlift

HL0890

1
OPEN HOOD OF VEHICLE USING ROD TO KEEP HOOD OPEN WHILST YOU WORK

2
RIGHT HAND SIDE FENDER
Remove both bolts

D
Fit the Bottom Bracket.
Replace both bolts to secure.

3
LEFT HAND SIDE FENDER
Remove both bolts

C
Fit the Bottom Bracket.
Replace both bolts to secure.

4
On the hood remove the top bolt and leave the bottom bolt in place

5
Bracket slides on to the remaining bolt
Replace the top bolt that was removed.
Ensure Ball Stud on bracket is facing away from the vehicle.

6
THEN REPEAT SLIDES 4 - 5 ON RHS HOOD

7
Fit the Lift-O-Mat to the hood first on both sides with the piston rod facing down.
Then lift the hood slightly and remove the Rod and fold away.

8
Fit the Ball Socket onto the Fender Bracket Ballstud on RHS

9
LEFT HAND SIDE HOOD & FENDER
Fit the Ball Socket to the Fender Bracket Ball Stud on LHS

10
Left hand side & right hand side hood and fender

NB: After installation open Hood/Bonnet gently to ensure that there is no interference with any hardware.

FITTING KIT CODE	MANUFACTURER	MODEL TYPE	YEAR	PRODUCT	REVISION	LABOUR TIME	DATE	PAGE
HL0890	VOLKSWAGEN	AMAROK	2016 2ND INTRO	EZUp	3	30min	05/10/2017	1
TORQUE-N.m	★ 25N.m ± 2N.m							

IMPORTANT: No liability will be incurred by Industrial Specialised Applications company, for injury, death, or property damage caused by a product which has been set up, operated, and/or installed contrary to EZUp installation guide/manual, or which has been subjected to misuse, negligence, or accident, or which has been repaired or altered by anyone other than Industrial Specialised Applications, or which has been used in a manner or for a purpose for which the product was not designed.