





GB	Removal	S	Demontering	CZ	Odmontování	中文	拆除
D	Demontieren	FIN	Irrutus	SK	Demontáž	日本語	取り外し
F	Démontage	EST	Eemaldamine	SLO	Odstranjevanje	한국어	분리
NL	Demontage	LAT	Noņemšana	HR	Uklanjanje	ไทย	การถอด
I	Rimozione	LIT	Nuėmimas	HU	Leszerelés		
E	Desmontaje	PL	Wymontowywanie	GR	Αφαίρεση		
PT	Remoção	RU	Снятие	TR	Sökme		



THULE®

SWEDEN

- GB** Fitting instructions
- D** Montageanleitung
- F** Instructions de montage
- NL** Montage-instructies
- I** Istruzioni per il montaggio
- E** Instrucciones de montaje
- PT** Instruções de Montagem
- S** Monteringsanvisning
- FIN** Asennusohje
- EST** Paigaldusjuhend
- LAT** Stiprināšanas instrukcija
- LIT** Pritvirtinimo instrukcijos
- PL** Instrukcja montażu
- RU** Инструкции по установке
- CZ** Návod na montáž

- SK** Návod na montáž
- SLO** Navodila za pritrjevanje
- HR** Uputa za sastavljanje
- HU** A felszerelés módja
- GR** Οδηγίες συναρμολόγησης
- TR** Montaj talimatları
- 中文 安装说明
- 日本語 取扱(取付)説明書
- 한국어 장착 지침
- ไทย คำแนะนำการติดตั้ง



Follow me...

THULE®

SWEDEN

Box 69, 330 33 Hillerstorp, SWEDEN
www.thule.com

607•4DF/501-7022-02



THULE

GB Security regulations
D Sicherheitsvorschriften
F Instructions importantes
NL Veiligheidsvoorschriften
I Norme di sicurezza
E Reglas de seguridad
PT Normas de segurança
S Sakerhetsföreskrifter
FIN Turvallisuusohjeet
EST Ohutusjuhised
LAT Drošības noteikumi
LIT Saugumo taisyklės
PL Bezpieczeństwo
HU Biztonságvesztély utasítások
CZ Měření na montáž
SK Bezpečnostné pokyny
SLO Varnostni predstavi
HR Pravila sigurnosti
SV Säkerhetsföreskrifter
TR Güvenlik kuralları
RU Правила безопасности

