



Cordless  
two speed  
drill/driver

K 10613



## **SAFETY AND PRECAUTION**

- 1 Consider work area environment. Do not expose tools to rain. Do not use tools in damp or wet locations – Keep work area clean and well lit. Do not use tools in the present of flammable liquids or gases.
- 2 Guard against electric shock. Avoid body contact with earthed or grounded surfaces.
- 3 Keep children away. Do not let visitors touch the tools or extension cord. All visitors should be kept away from work area.
- 4 Store idle tools. When not in use, tool should be stored in a dry locked up place, out of reach of children.
- 5 Do not force the tool. It will do the job better and safer at the rate for which it was intended.
- 6 Stay alert. Watch out what you are doing–Use common sense. Do not operate tool when you are tired. Check damaged parts. Before further use of the tool, a guard or other part is damaged should be carefully checked to determine that it will operate properly and perform its intended function.
- 7 Check for alignment of moving parts, blinding of moving parts, breakage of parts, mounting and any other condition that may affect its operation.
- 8 A guard or other parts that is damaged should be properly repaired or replaced by an authorized service center unless otherwise indicated in this instruction manual. Have defective switches replaced by an authorized service center. Do not use tool if switch does not turn it on.
- 9 To ensure the designed operational integrity of power tools, do not remove installed cover or screws.
- 10 Use your tool at lower input than specified on the nameplate, otherwise, the finish may be spoiled and working efficiency reduced by motor overload.
- 11 Do not wipe plastic parts with solvent. Solvents such as gasoline, thinner, benzene, carbon tetrachloride, alcohol, ammonia and oil containing chloric annex may damage and crack plastic parts. Do not wipe them with such solvent. Wipe plastic parts with a soft cloth lightly dampened with soap water.
- 12 Dress properly. Do not wear loose clothing or jewellery. Contain long hair keep your hair, clothing and gloves away from moving parts.
- 13 Use safety equipment. Always wear eye protection, non-skid safety shoes, hard hat, or hearing protection.
- 14 Do not overreach. Proper footing and balance enables better control of the tool in unexpected situations.

## **PRODUCT SAFETY INSTRUCTIONS**

- 1 Disconnect battery pack from tool or place the main switch in the locked or off position before making any adjustments, changing accessories, or storing the tool. Such preventative safety measures reduce the risk of starting the tool accidentally.
- 2 Remove adjusting keys or wrenches before turning the tool on . A wrench or a key that is left attached to a rotating part of the tool may result in personal injury.
- 3 Use clamps or other practical way to secure and support the work piece to a stable platform. Holding the work by hand or against your body is unstable and may lead to a loss of control.
- 4 Maintain tools with care. Keep cutting tools sharp and clean. Properly maintained tools, with sharp cutting edges are less likely to bind and are easier to control.
- 5 Use only accessories that are recommended by the manufacturer for your model. Accessories that may be suitable for one tool may create a risk of injury when used on another tool.

## **IMPORTANT SAFETY INSTRUCTIONS FOR CHARGER & BATTERY PACK**

- 1 Caution: To reduce risk of injury, charge only specific type rechargeable battery packs. Other types of battery packs may burst causing personal injury and damage.
- 2 Before using charger, read all instructions and cautionary markings on battery packs and chargers.
- 3 Do not expose charger to rain or snow.
- 4 To reduce the risk of damage to electric plug and cord, pull by plug rather than cord when disconnecting charger.
- 5 Use of an attachment not recommended or sold by the charger manufacture may result in a risk of fire, electric shock, or injury to persons.
- 6 Make sure cord is located so that it will not be stepped on, tripped on, tripped over, or otherwise subjected damage or stress.
- 7 Do not operate charger with damaged cord or plug. Replace them immediately.
- 8 Do not operate charger if it has received a sharp blow, been dropped, or otherwise damage in any way, take it to qualified center.
- 9 To reduce risk of electric shock, unplug charger from outlet before attempting any maintenance or cleaning. Turning off controls will not reduce this risk.
- 10 Do not disassemble charger or battery pack, take it to a qualified service center while repair is required. Incorrect reassembling may result in a risk of electric shock or fire.

## ADDITIONAL SAFETY RULES FOR CHARGER & BATTERY PACK

- 1 Do not charge battery pack when temperature is below 10°C (50°F) or above 40°C (104°F).
- 2 Do not attempt to use a set-up transformer, an engine generator or DC power receptacle.
- 3 Do not allow anything to cover or clog the charger vents.
- 4 Always cover the battery pack terminals with the battery pack cover when the battery pack: is not used.
- 5 Do not short the battery pack.
- 6 Do not touch the terminals with any conductive material.
- 7 Avoid storing battery pack in a container with other metal objects such as nails, coins, etc.
- 8 Do not expose battery pack to water or rain, A battery pack short can use large current flow, overheating, possible burns and even a breakdown.
- 9 Do not store the machine and battery pack in locations where the temperature may reach or exceed 50°C (122°F)
- 10 Do not incinerate the battery pack even if it is severely damaged or completely worn out. The battery pack can explode in a fire.
- 11 Be careful not drop, shake or strike battery pack.
- 12 Do not charge inside a box or container of any kind. The battery pack must be placed in a well ventilated area during charging.
- 13 Do not leave batteries unused for extended period of time. Recharge the battery every 3–6 months and bring Li-Ion battery to 40–80% charge level before storage.
- 14 Li-Ion batteries are sensitive to high temperature and should be kept in a cool, dry and out of direct light exposure. Ideal temperature for operation and storage is below 25°C (77°F).
- 15 This product is designed with low voltage protection, which prevents the tool from over discharging and prolong battery's life span.

## SPECIFIC SAFETY RULES AND/OR SYMBOLS



Recycle



Do not throw in garbage

a.c. Alternating current

W Watts

mm Millimeter

Nm Newton meter

rpm Revolutions or Reciprocations per minute



Class II tool

V Volts

Hz Hertz

kg Kilograms

d.c. Direct current

ft-lb Foot-Pound

## PRODUCT SPECIFICATIONS

Model No.	K 10613
Voltage	18V DC
No load speed/min	Low: 0–1220 rpm High: 0–340 rpm
Max Torque	45 Nm (33 ft-lb)
Tool weight (with battery)	2.08 kg
Chuck capacity	Keyless 1/2" (13 mm)
Clutch	17 sections
Charging Time	1 hour Auto Cut-Off

## MAJOR COMPONENTS



## ACCESSORY

Charger



# OPERATING INSTRUCTIONS

## INSTALLING OR REMOVING BATTERY PACK

(See Fig.1 Fig.2)

- 1 Always switch off the machine before insertion or removal of the battery pack.
- 2 To remove the battery pack, push the button on the battery pack and pull the tool unit from the battery pack in the direction.(See Fig.1.)
- 3 To insert the battery pack, align the tool unit slides with the battery pack sliding groove and push the tool unit into place. (See Fig.2)
- 4 Do not force the battery pack in sliding it into tool unit. If the battery pack does not slide in easily, it is not being inserted correctly.



Fig 1



Fig 2

## CHARGING THE BATTERY PACK

(See Fig.3)


- 1 Plug the fast charger into the power source.
- 2 Slide the battery pack into the charger as the arrow direction shown on the charger.
- 3 Push the battery pack into place and make sure the red light on the charger is "ON". The battery pack is now starting the charging cycle.
- 4 After finish the charging cycle, the light will turn into green. The battery pack is now ready for use.
- 5 Your new battery pack is not charged. You need to charge it before use.
- 6 If you try to charge a battery pack from a just-operated machine, sometimes the charging light will not come on. If this occurs, let the battery pack cool for a while then re-insert it and try to charge again.
- 7 When you charge a new battery pack or a battery pack which has not been used for a long period, it may not accept a full charge. This is a normal condition and does not indicate a problem. You can recharge the battery pack fully after discharging it completely a couple of times.
- 8 While charging the second battery, allow the charger to cool down for 15 minutes before start the second charging process.
- 9 Unplug the charger from the power source after finish the charge.



Fig 3

## LED INDICATION FUNCTION

The Battery Pack has a “SW” button and 4-step green LEDs for indicating remaining capacity status and Over temperature condition. The remaining capacity (RC) and temperature protection status green LED indications (3 seconds) when the “SW” button is momentarily pressed.



LED Indication	RC Status	LED Indication	RC Status
LED 1 (green)	0%- 25%	LED 1, 2, 3, 4 (green)	76%-100%
LED 1, 2 (green)	26%-50%	LED 1 blinking (0.25 sec/green)	Fully Depleted
LED 1, 2, 3 (green)	51%-75%	LED 1, 2, 3, 4 blinking (0.5 sec/ green)	Over temperature condition

## LED LIGHT ON THE CHARGER



Power On (Green light flashes slowly)



Battery low (Red light stays illuminated)



Battery charged 80% (Green light flashes rapidly)



Battery charged 100% (Green light stays illuminated)



Battery pack temperature is too hot or too cold (Red light flashes slowly)



Battery pack malfunction (Red and Green lights stay illuminated)



- 1 Charger can only be plugged into a 100-240V a.c outlet.
- 2 If the battery pack is too hot or too cold, the charger will not fast charge the battery pack and the red Indicator light is “blinking”. When the battery pack temperature returns to between 0°C and 50°C, the charger will automatically begin charging.
- 3 If both red and green indicator lights are “ON” the battery pack either does not comply or is defective. Please contact your retailer.
- 4 Do not charge the battery pack in rain, snow or high temperature environment.
- 5 Do not charge battery pack when temperature is below 10°C (50°F) or above 40°C (104°F)
- 6 While charging a cool battery pack (below 5°C or 41°F) in warm indoor temperatures, keep the battery pack in the room for one hour to warm up before charging. A cool battery may charge unsaturated.
- 7 Remove the plug after finishing the charge.
- 8 Do not use generator for charging the battery pack


# TOOL OPERATING

## HOW TO INSERT AND REMOVE BITS

- 1 To insert a bit, turn the chuck clockwise.
- 2 To remove a bit, turn the chuck counterclockwise.

## FORWARD/REVERSE KNOB SELECTION BUTTON

Select the forward or reverse direction of the tool by pushing the Forward/Reverse knob.



## HIGH/LOW SPEED SELECTION

Use the "High" for drilling application.

Use the "Low" for screwdriver application.

## SELECT THE APPLIED TORQUE



Use the 17 sections adjustment ring to select the right torque for your application.

## DRILL MODE


Turn the torque ring to the sign for the maximum torque position if you would like to drill on wood.

## REPLACEMENT OF THE CHUCK

- 1 Turn chuck counter clockwise until it is fully open
- 2 Release the left hand screw inside the chuck



# PARTS K 10613



## PARTS LIST K 10613

No	Parts name	Qt	Spare part No
1	Chuck screw	1	
2	Keyless chuck	1	
3	Gear boc ass'y	1	K 10265
4	High/low speed knob	1	K 10267
5	Knob spring	1	
6	Speed change ring	1	
7	Motor connector	1	
8	Screw	2	
9	Motor ass'y	1	K 10266
10	Forward/reverse knob	1	
11	Main switch	1	K 10268
12	Discharge protector	1	
13	Battery connector	1	
14	Housing L&R	1	
15	Belt	1	
16	Soft grip	1	
17	Housing screw	7	
18	Housing label (R)	1	
19	Housing label (L)	1	
20	Battery pack	1	K 10615
21	Charger	1	K 10616
22	Battery label	1	
23	Fuel gauge label	1	
24	Power cord	1	



K 10613

[www.kamasatools.com](http://www.kamasatools.com)